PARTS LIST

No.	Description	Qty
1	Chuck core assembly	1
2	Dust cover	1
3	Rubber sleeve	1
4	Head shell	1
5	Phillips pan head self-tapping screw ST4.2x30	4
6	Output shaft	1
7	6001 bearing	1
8	Elastic circlip for shaft	1
9	Bearing 6200	1
10	Elastic circlip for hole	1
11	Middle cover	1
12	608 bearing	1
13	Hole elastic retainer ring	1
26	Connecting sleeve	1
25	Compression spring	1
23	Rotor	1
14	607 bearing	1
15	Switch push block	1
16	Switch lever	1
17	Controller component	1
18	Right machine case	1
19	Electricity display button	1
20	Tapping screw ST3.5x16	5
21	Switch	1
22	Dust cover	2
24	Left machine case	1
27	Plug pin	1
28	Wrench	1

ASSEMBLY DIAGRAM

