

### PARTS LIST

Part	Description	Qty	Part	Description	Qty
1	Screw M5x25-left	1	27	607 Bearing	1
2	Chuck 13MM	1	28	607 Bearing sleeve	1
3	Screw ST4×35	3	29	Screw ST4×60	2
4	Gear Box	1	30	Stator	1
5	6201 Bearing	1	31	Motor housing	1
6	Ring Ø32	1	32	Bubble	1
7	Cylinder pin Ø5X14	1	33	Screw ST4×16	6
8	Square key 3X8	1	34	Handle cover	1
9	Output shaft	1	35	Screw ST3×10	4
10	External Circlips Ø12	1	36	coil spring	2
11	Gear	1	37	Carbon brush holder (left)	1
12	External Circlips Ø10	1	38	Inductance	2
13	Taper spring	1	39	Carbon brush 5.5×10.5*18.5	2
14	Wool block	2	40	Carbon brush holder (right)	1
15	Impact tooth	1	41	Switch	1
16	Gasket	1	42	Capacitance 0.33	1
17	688 Bearing	1	43	Screw ST4×14	2
18	Impact block	1	44	Wire plate	1
19	Shifting block seat	1	45	Guard sleeve	1
20	Impact iron sheet	1	46	Power cable	1
21	Intermediate lid	1	47	Bolt M8 × 115	1
22	Oil deflector	1	48	Aluminum Bracket	1
23	608 Bearing	1	49	Auxiliary handle	1
24	Wind Guide	1	50	Metal Depth guage	1
25	Armature	1	51	Key	1
26	Ring	1			

### ASSEMBLY DIAGRAM

