

PARTS LIST

No.	Description	Qty	No.	Description	Qty
1	Hammer rod protector	1	64	Retaining Ring 12x1	1
2	Steel Circlip Φ 25x2	1	65	Small clutch spring Φ 28.2x2.8x16.8	1
3	Support Washer	1	66	Clutch spring seat	1
4	Flex Sheath	1	67	Retaining Ring 8.8x1	1
5	Flex Sheath Spring	1	68	Ball Bearing 628	1
6	Retaining Ring Φ 55	2	69	Crank Shaft	1
7	O Ring Φ 58x1.5	1	70	Flat Key 4x4x12	2
8	Oil seal gasket	1	71	Ball Bearing 6204	1
9	Oil Seal Ring Φ 35x51x6	2	72	Retaining Ring Φ 47	1
10	Steel Circlip Φ 32x1.8	1	73	Liner	1
11	Ball Bearing 6907	1	74	Crankshaft gear	1
12	Front housing	1	75	Retaining Ring Φ 16	1
13	Hex .Socket Bolt Set M6x25	4	76	Ball Bearing 6000	1
14	O Ring 54x1.9	1	77	Seal Ring for Inner cover	1
15	Hammer Staff Sheath	1	78	Inner Cover	1
16	Steel Ball S Φ 8	2	79	Hex .Socket Bolt M6*14	1
17	O Ring Φ 24.1x2.1	1	80	Hex .Socket Bolt Set M5x20	2
18	Steel Pillar Φ 8x8	3	81	Hex .Socket Bolt Set M6x25	3
19	Impact Hammer Assembly	1	82	Housing Cover	1
20	O Ring Φ 24x1.9	1	83	Shock Absorption Spring	2
21	Hammer ring	2	84	Shock Absorption Ferrule	1
22	Vibration Reducing Cushion	1	85	Shock-absorbing pillar	2
23	Steel Pillar Retaining ring	1	86	Shock Absorption Jacket	1
24	Cylinder	1	87	Oil Seal Ring Φ 12x Φ 22x5	1
25	Flat Key 3x3x18	2	88	Washer Φ 28x16x1	1
26	Retaining Ring Φ 32x1.8	1	89	Ball Bearing 6001	1
27	Impact Piston	1	90	Bearing Plate	1
28	O Ring Φ 22x3.05	1	91	Fan Guide	1
29	Cylinder Spring	1	92	Armature	1
30	Spring Ring	1	93	Flat Washer Φ 14x8x0.9	1
31	Steel Circlip	1	93-1	Flat Washer Φ 16*8*1.5	1
32	Clutch Spring	1	94	Isolation Ring	1
33	Clutch	1	95	Stator	1
34	Big Cone-shaped Gear	1	96	Self-Tapping Screw ST5x60	2
35	Retaining Ring Φ 50	1	97	Ball Bearing 608	1
36	Oiliness Bearing Φ 34x Φ 50x10	1	98	Hex .Socket Bolt Set M6x20	4
37	Gas Press Piston	1	99	Housing	1
38	Piston Pin	1	100	Carbon Brush	2
39	O Ring Φ 22x3.05	1	101	Brush Carrier Subassembly	2
40	Connecting Rod Ass'y	1	102	Coil spring	2
41	Needle Bearing HK10/20	1	103	Tapping Screw ST3x10	4
42	Washer 5.2*25*2.5	1	104	Fan Cover	1
43	Hex .Socket Bolt Set M6x16	1	105	Self-Tapping Screw ST4x16	3
44	Oil Tank Cover	1	106	Tapping Screw ST3x10	2
45	O Ring Φ 42x2	1	107	Speed Adjuster	1
46	Top Cover	1	108	Main Handle Seat	1
47	Rubber gasket	1	109	Screw 5x16	4
48	Hex .Socket Bolt M5x16	6	110	Hex .Socket Bolt M6x50	1
49	Crank Housing	1	111	Left Handle	1
50	O Ring Φ 22x2	1	112	Switch button	1
51	Dial Staff Sheath	1	113	Switch	1
52	Retaining Ring Φ 25	1	114	Capacitance	1
53	Function Knob	1	115	inductor	2
54	Function Knob Spring	2	116	Right Handle	1
55	Function Knob Button	1	117	Self-Tapping Screw ST4x16	3
56	Machine Screw ST4x14	1	118	Nut M6	1
57	Small bevel Gear	1	119	Cord Slip	1
58	Ball Bearing 6002	1	120	Cord Armor	1
59	Wearable Flat	1	121	Cord	1
60	Big Flat Gear	1	122	Steel Tie For Side Handle Ass'y	1
61	Clutch fixing Plate	1	123	Square Bolt	1
62	Steel Pillar 5*6	6	124	Side Handle Ass'y Base	1
63	Clutch Movable Plate	1	125	Side Handle	1

ASSEMBLY DIAGRAM

