

PARTS LIST

Part	Description	Qty	Part	Description	Qty
1	Rag wheel	1	25	608 Bearing leather collar	1
2	Output spindle	1	26	screw	2
3	Semicircle key ø10x3	1	27	Guided ring	1
4	Pan head screws M5x14	4	28	Stator	1
5	Front cover	1	29	housing	1
6	Bearing 6201-2RS	1	30	coil spring	2
7	Pan head screws M4x8	3	31	Carbon brush	2
8	D type handle	1	32	Brush holder	1
9	Gear	1	33	screw	2
10	Retainer ring ø12	1	34	Right cover	1
11	Needle roller bearings HK0810	1	35	screw	2
12	Hexagon socket head cap screws M8x20	2	36	Speed controller cover	1
13	handle set piece	2	37	Switch(right self-lock)	1
14	screw	4	38	Right handle	1
15	Gear Box	1	39	screw	6
16	Retainer ring ø12	1	40	Cable cover	1
17	Lock pin spring	1	41	Cable plug	1
18	Lock pin	1	42	Cable pressboard	1
19	Retainer ring ø12	1	43	screw	2
20	bearing 6001	1	44	Speed controller	1
21	screw	3	45	Left handle	1
22	Rotor	1	46	Left cover	1
23	Spanner	1	47	Brush holder	1
24	Bearing 608	1			

ASSEMBLY DIAGRAM

