

**PARTS LIST**

Description	Position
Pad holder	1
spindle, wedge	2, 3
Bearing 6201RS	7
Big gear	8
Bush	10
Locking pin assembly	11, 13, 14
Bearing 6001 + ring	16, 17
Rotor + heat guard	19, 20
Bearing	21
Bearing cover	22
Stator	24
Carbon brush cap (2pcs)	27
Carbon brush (2pcs)	28
Carbon brush holder (2pcs)	29
Speed regulator	34
Switch	33, 35
Handle	41
Bolt (2pcs) and ring (2pcs)	42, 43

### ASSEMBLY DIAGRAM

