PARTS LIST

Part	Description	Qty	Part	Description	Qty
1	Plug	1	28	Spring Washer	8
2	Battery Clip	1	29	Nut	8
3	Power Cord	1	30	Transformer Support	4
4	Screw	4	31	E- Steel Shee	1
5	Flat Washer	8	32	I- Steel Shee	1
6	Cable	2	33	Mian Winding	1
7	Spring Washer	4	34	Thermostat	1
8	Nut	4	35	Screw	2
9	Rubber Footing	4	36	Flat Washer	5
10	Cable Grip	2	37	Spring Washer	3
11	Base Plate	1	38	Nut	3
12	Output Fuse	1	39	Screw	1
13	Output current switch	1	40	Kbpc Bridge Rectifier	1
14	Nut	1	41	Radiator	1
15	Fuse Tube Socket	1	42	Thermostat	1
16	Fuse Tube	1	43	Screw	1
17	Fuse Cover	1	44	Thermostat Support	1
18	Voltage Switch	1	45	Screw	1
19	Sheath of meter	1	46	Tapping Screw	12
20	Fastener	2	47	Housing Cover	1
21	Current meter	1	48	Handle Belt	1
22	Fuse Holder	1	49	Handle Steel Belt	1
23	Power Switch	1	50	Handle Belt Button	2
24	Tapping Screw	2	51	Screw	2
25	Current Diverter	1	52	Flat Washer	2
26	Screw	4	53	Spring Washer	2
27	Flat Washer	16	54	Nut	2

ASSEMBLY DIAGRAM

