

PARTS LIST

No.	Part Description	Qty
1	Right Housing	1
2	Screw,M3.5X15-L	8
3	Spring strip	2
4	Variable speed knob	1
5	Spring strip	1
6	F/R Lever	1
7	Transparent Cover	1
8	switch ASS'Y	1
9	contact plate	1
10	Screw,M3X6	2
11	Clamp Plate	1
12	Torsion ring	1
13	Internal thread	1
14	Spring	6
15	Spring strip	1
16	Bracket	1
17	Impact of cup	1
18	Impact cup holder	1
19	Screw, M5X25-L	1
20	Chuck	1
21	Output shaft	1
22	Bearing	1
23	Plate	1
24	Impact gear	1
25	Impact spring	1
26	Impact end teeth	1
27	Clamp Plate	1

No.	Part Description	Qty
28	Bearing	1
29	O-ring	1
30	Spring strip	1
31	Gear box	1
32	pin, Ø4.5X9.0	6
33	Shaft lock seat	1
34	Pin, Ø4.3x6.2	3
35	Sun gear disk	1
36	Ring gear-3rd	1
37	planetary gear-3rd	3
38	Flat washer	1
39	Pin,Ø3x35.6	2
40	Frong gear box	1
41	Sun gear-2nd	1
42	Planet gear-2nd	4
43	Sun gear-1st	1
44	Ring gear-1st	1
45	Planetary gear-1st	3
46	Flat washer	1
47	Screw, M3X6	2
48	Motor bracket	1
49	Motor gear	1
50	Motor	1
51	Damping rubber boot	1
52	Left Housing	1
53	Battery	1
54	Charger	1

ASSEMBLY DIAGRAM

