

PARTS LIST

Part	Description	Qty
1	Sticker	1
2	Upper cover	1
3	Hex wrench M8×16	1
4	Big washer 8X22X2	1
5	Outer flange	1
6	Blade	1
7	Clamplng flange	1
8	screwM4×10	6
9	Flange for lower guard	1
10	Lower guard	1
11	Screw M4×8	1
12	Spanner for lower guard	1
13	Spring $\phi 3.8 \times 0.7 \times 98$	1
14	Output shaft	1
15	Semi-circular key3×10	1
16	bearing6001-2RS	1
17	Front cover	1
18	Washer 12	1
19	Big gear	1
20	Washer 10	1
21	Screw M6×18	1
22	Bearing 8C7×14×8	1
23	Screw M5×18	1
24	Washer	1
25	Elastic cylindrical pin 6×35	1
26	Head cover	1
27	Screw M4×12	4
28	washer 4	3
29	Screw M5×35	1
30	Rear coverf for exit dust	1
31	Board	1
32	Self –pin	1
33	Bearing 6000-2RS	1
34	Spring $\phi 5.9 \times \phi 0.7 \times 10$	1
35	Rotor	1

Part	Description	Qty
36	Wind loop	1
37	Screw ST4.2×60	2
38	Stator	1
39	Connect pin 8.5	2
40	Bearing 607-2RS	1
41	Bearing jacket	1
42	Housing	1
43	Specification sticker	1
44	Carton brush cover	2
45	Carbon brush	2
46	Brush holder 6×10×24	2
47	Rear cover	1
48	Screw ST4.2×16-F	8
49	Screw M5×50	2
50	Left handle	1
51	capacitor 0.22 μ F×2	1
52	Switch	1
53	Right handle	1
54	Cable presser 70T-16-02	1
55	Cable jacket10T-20	1
56	Cable 2×0.75mm2	1
57	riviter 5×7	2
58	Locking knob	1
59	Flat washer $\phi 6 \times \phi 14 \times 1.5$	2
60	Angle frame	1
61	nutM4	1
62	Screw M4×10	1
63	Spring $\phi 8.2 \times 0.8 \times 3$	1
64	Pressing knob	1
65	Bolt M6×14	1
66	Base	1
67	locking rob fordepth	1
68	Depth frame	1
69	Spanner 6	1
70	Guide	1

ASSEMBLY DIAGRAM

