

PARTS LIST

Part	Description	Qty	Part	Description	Qty
1	Flange nut M6 X18	1	28	Screw ST4.2X16	4
2	Outer flange	1	29	Screw M5X25	3
3	Inner flange	1	30	Brush holder	2
4	Spindle	1	31	Carbon brush	2
5	Steel Bushing	1	32	Brush cover	2
6	Skeleton Oil Seal	1	33	Cord protector	1
7	Screw M5X16	2	34	Cord and plug	1
8	Front cover	1	35	Cable Platen	1
9	Bearing 6002	1	36	Ttigger Dust Cap	1
10	Circlip 32	1	37	Self-locking Dust Cap	1
11	Wheel gear	1	38	Switch	1
12	Bearing 606	1	39	Capacitor	1
13	Gear box	1	40	Handle Cover	1
14	Screw M7x1	1	41	Screw M6×25	1
15	Pinion gear	1	42	Iron set $\phi 12 \times \phi 6.5 \times 15$	1
16	Bearing 629	1	43	Base Plate	1
17	Rectangular Circle	1	44	Screw M6×40	1
18	Characteristics of the gasket	1	45	Screw M6×7	1
19	Rotor assy	1	46	Nut M6	1
20	Anti-dust Ring	1	47	Spanner	1
21	Bearing 608	1	48	Wrench	1
22	Bearing sleeve	1	49	Water-valve	1
23	Wind guard	1	50	Screw M4×12	1
24	Screw ST4.2X65	2	51	Water pipe	1
25	Stator assy	1	52	Water connector	1
26	Electric ring	2	53	Carbon brush	2
27	Housing	1			

ASSEMBLY DIAGRAM

