

PARTS LIST

No.	Description	No.	Description
1	Nut M10	47	Male Tab
2	Base	48	Laser Switch
3	Big Fence	49	Spring
4	Washer $\Phi 16 \times \Phi 8 \times 1$	50	Cap of case
5	Standard spring washer 8	51	Battery
6	Cross screw M8X25	52	Spring
7	Bolt M6X35	53	Battery Case
8	Active Fence	54	Vise clamp
9	Fence Flat	55	Vise Bolt
10	Hexagon nut M6	56	Vise Handle
11	Fence Wrench	57	Connect Bar
12	Big Washer $\Phi 18 \times \Phi 6 \times 1.5$	58	Screw M6x15
13	Nut M6	59	Stand Bar
14	Cross screw M5X12	60	Screw
15	Stand Bar	61	Angel Locatin Pin
16	Angle lock handle cap	62	Tilt Indicator
17	Cross screw M5X16	63	Connect Head
18	Standard spring washer 5	64	Screw
19	Washer $\Phi 10 \times \Phi 5 \times 0.5$	65	Knob
20	Angle Lock handle	66	Spring
21	Screw	67	Button
22	Angle lock handle cushions	68	Shim $\Phi 17 \times \Phi 11 \times 1.5$
23	Washer $\Phi 20 \times \Phi 10 \times 2$	69	Nut M8
24	Nut	70	Circlip 40
25	Support Nut	71	Linear Bearing
26	Spring	72	Wool Ring
27	Cross screw M5X50	73	Dust Cap
28	Trigger Housing	74	Screw M5X12
29	Coach Spring	75	Heel
30	Nut M5	76	Screw M6X10
31	Switch button	77	Cover
32	Washer	78	Spring
33	Washer	79	Knob
34	Spring	80	Washer $\Phi 12 \times \Phi 6 \times 1$
35	Angle lable	81	Sliding Bar
36	Rotation Plate	82	Nut M16
37	Slotted Plate	83	Cushion Ring $\Phi 30 \times \Phi 17 \times 2$
38	Washer $\Phi 18 \times \Phi 12$	84	Screw M6X8
39	Hexagon Bolt M10X30	85	Bracket
40	Hexagon Bolt M8X40	86	Cross screw M8X12
41	Hexagon nut M8	87	Depth Adjustment Plate
42	Hexagon Bolt M8X50	88	Washer $\Phi 13 \times \Phi 8$
43	Laser Stand	89	Screw
44	Cross screw M4X10	90	Big Spring
45	Laser	91	Washer A
46	Screw M4X6		

PARTS LIST

No.	Description	No.	Description
92	Rocker pin	139	Housing
93	Upper Limited Sheath	140	Brush Holder
94	Oil seal 5	141	Carbon Brush
95	Cap of Pin	142	Cap of Brush holder
96	Blade Guard Board	143	Rear Cover
97	Spring	144	Screw ST4X10
98	Trigger	145	Connect
99	Locking Seat	146	Screw
100	Cross screw M5X40	147	Guard plate
101	Spring	148	Cross screw M5X10
102	Split Washer 6	149	Coil Spring
103	Locking Button	150	Protection Cover
104	Spindle Locking Pin	151	Guard scale board
105	Blade Cover	152	Screw 5*8
106	Cross screw M5X30	153	Screw
107	Belt Cover	154	Screw
108	Belt PJ356mm	155	Bearing Clip
109	Belt PJ338mm	156	Guide Wheel
110	Cross screw M6X20	157	Guide Bushing
111	Standard spring washer 6	158	Spindle
112	Washer $\Phi 25 \times \Phi 6 \times 2$	159	Flange Bushing
113	Big Belt Wheel	160	Flange
114	Bearing 6202	161	Blade
115	Cross screw M8X20	162	Blade cushions
116	Washer $\Phi 30 \times \Phi 8 \times 2$	163	Screw M8X16
117	Big Ratio Wheel	164	Screw ST4X16
118	Small Ratio Wheel	165	Under Handle
119	Cross screw M6X16	166	Spring
120	Hexagon Bolt M6X30	167	Switch
121	Bearing Gland	168	Trigger
122	Bearing 6203	169	Upper Handle
123	Flat Key (HRC28-35) 5X25	170	Cross screw M5X55
124	Belt Roller	171	Handle
125	Bearing Pressure Ring	172	Screw ST5X60
126	Hexagon nut M10	173	Power Cord (1*3C)
127	Small Belt Wheel	174	Ring
128	Washer 4	175	Cable clamp
129	Standard spring washer 4	176	Cross screw M6X16
130	Cross screw M4X8	177	Washer $\Phi 15 \times \Phi 10$
131	Wire Cover	178	Cradle
132	Washer $\Phi 8 \times \Phi 4 \times 0.5$	179	Cradle Fence
133	Cross screw M4X12	180	Label
134	Armature	181	Label Rivet $\Phi 2 \times \Phi 4$
135	Screw ST5X65	182	Wrench
136	Stator	183	Dust Bag
137	Connect Wire(1x3C)		
138	Bearing 6200		

ASSEMBLY DIAGRAM

