

PARTS LIST

Part	Description	Qty	Part	Description	Qty
1	PUMP BODY	1	22	SPRING WASHER M8	1
2	WATER SEAL	3	23	BEARING	1
3	INPUT WATER CHECK VALVES	3	24	SWASHPLATE	1
4	ALUMINUM RING	3	25	BEARING 6303	1
5	OIL SEAL RING	3	26	SKELETON OIL SEAL	1
6	OIL SEAL	3	27	HYDRO CYLINDER	1
7	PUMP BASE	1	28	ROTOR	1
8	O RING 70*2	1	29	REAR BEAR 6202	1
9	PLUNGER SPRING	3	30	STATOR	1
10	PLUNGER	3	31	MACHING LEG	2
11	PRESSURE RETAINING VALVE	1	32	FAN	1
12	6 TEETH SHEET	1	33	FAN COVER	1
13	MICRO SWITCH BOX	1	34	SCREW 4*8	3
14	SPOOL	1	35	SCREW OF MOTOR	4
15	LATCH 3.5MM	1	36	SWITCH	1
16	O RING 21*2.5	1	37	HOUSING SCREW M5	4
17	PRESSURE GAGE	1	38	HOUSING FOOT SCREW M5	4
18	PLUG SCREW	2	39	MACHINE HOUSING	1
19	WATER OUTPUTHEAT CHECK VALVE	3	40	CABLE SHEATH	1
20	SCREW M5X65	4	41	CABLE	1
21	SCREW M8X18	1	42	REAR COVER	1

ASSEMBLY DIAGRAM

