

PARTS LIST

No.	Description	Qty	No.	Description	Qty
1	Cradle	2	33	Spring	1
2	Screw M5X12	24	34	Bolt M6X35	1
3	Screw M6×15	2	35	Fence	1
4	Cradle Fence	1	36	Active Fence	1
5	Nut M10	1	37	Flat WasherØ20XØ8X2	4
6	Base	1	38	Screw M8X25	4
7	Angle lock handle cap	1	39	Fence Press Block	1
8	Screw M6X16	1	40	Nut M6	1
9	Standard spring washer 6	1	41	Lock Wrench	1
10	Flat WasherØ12×Ø6×1	1	42	Cushion Ring Ø18XØ6X1.5	1
11	Angle Lock handle	1	43	Nut M6	2
12	Screw	1	44	Tilt Indicator	1
13	Flat Washer Ø20XØ10X2	2	45	Trident Handle Wheel	1
14	Angle lock handle cushions	1	46	ShimØ17XØ11X1.5	2
15	Nut	1	47	WasherØ15XØ10.3	1
16	Rotation Plate	1	48	Nut M8	2
17	Standard spring washer 5	25	49	Screw	1
18	Flat WasherØ10×Ø5×0.5	42	50	Angel Locatin Pin	1
19	Angle lable	1	51	Screw M4X10	4
20	Support Nut	1	52	Battery	2
21	Flat WasherØ16XØ8X1	6	53	Spring	1
22	Spring	1	54	Battery Box	1
23	Screw M5X50	1	55	Battery Box Cap	1
24	Trigger Housing	1	56	Male Tab	1
25	Screw M5X16	8	57	Laser Switch	1
26	Trigger	1	58	Spring	1
27	Coach Spring	1	59	Laser	1
28	Nut M5	3	60	Laser Stand	1
29	Washer	1	61	Screw M4X6	3
30	Washer	1	62	Hexagon Bolt M8X45	1
31	Screw M8X25	2	63	Nut M8	2
32	Standard spring washer 8	9	64	Flat WasherØ20XØ10X2	2

PARTS LIST

No.	Description	Qty	No.	Description	Qty
65	Screw M10X25	1	97	Rocker pin	1
66	Hexagon Bolt M8X40	1	98	Screw M5X40	2
67	Label	1	99	Screw M5X30	5
68	Label Rivet Ø2XØ4	2	100	Belt Cover	1
69	Slotted Plate	1	101	Belt PJ457mm	1
70	Connect Head	1	102	Belt PJ338mm	1
71	Flat WasherØ12xØ6x1	2	103	Screw M6X16	3
72	Spring	1	104	Standard spring washer 6	4
73	Knob	1	105	Flat Washer Ø12xØ6x1	3
74	Circlip 45	4	106	Bearing Gland	1
75	Linear Bearing	4	107	Bearing 6203	3
76	Wool RingØ44xØ30x3	4	108	Nut M10	1
77	Dust Cap	2	109	Small Belt Wheel	1
78	Screw M5X12	4	110	Belt Roller	1
79	Heel	2	112	Bearing Pressure Ring	1
80	Screw M6X10	2	113	Screw M8X20	1
81	Cover	1	114	Flat Washer Ø30xØ8x2	1
82	Cap of Pin	1	115	Big Ratio Wheel	1
83	Split Washer 6	1	116	Small Ratio WheelØ30mmØ	1
84	Compression Spring	1	117	Flat Key(HRC28-35) 5X25	3
85	Oil seal 5	1	118	Screw M6X20	1
86	Pin	1	119	Flat Washer Ø25xØ6x2	1
87	Nut M16	1	120	Big Belt Wheel	1
88	Big WasherØ30xØ17x2	2	121	Bearing 6202	2
89	Screw M6X8	2	122	Blade Guard Board	1
90	Sliding Bar	2	123	Spring	1
91	Adjusted Screw	2	124	Trigger	1
92	Depth Adjustment Plate	1	125	Locking Seat	1
93	Screw M10X14	1	126	Spring	1
94	Standard spring washer 10	1	127	Split Washer 6	1
95	Bracket	1	128	Spindle Locking Pin	1
96	Big Spring	1	129	Locking Button	1

PARTS LIST

No.	Description	Qty	No.	Description	Qty
130	Blade Cover	1	162	Transparent Cover	1
131	Nut M6	2	163	Quakeproof Circle	1
132	Hexagon Bolt M6X30	2	164	Screw M6X12	2
133	Wire Cover	1	165	Guard plate	1
134	Flat Washer Ø10XØ 4X0.8	2	166	Spring	1
135	Standard spring washer 4	2	167	Dust Cover	1
136	Screw M4X12	2	168	Spindle	1
137	Armature	1	169	Front Cover	1
138	Screw ST5X70	2	170	Flange Bushing	1
139	Stator Cover	1	171	Outer Flange	2
140	Stator	1	172	Blade	1
141	Bearing 6000	1	173	Blade Cushions	1
142	Bearing Cover	1	174	Hexagon Bolt 8.8 M8X16	1
143	Housing	1	175	Screw ST4X16	4
144	Brush Holder Cap	2	176	Under Handle	1
145	Carbon Brush	2	177	Spring	1
146	Brush Holder	1	178	Switch	1
147	Rear Cover	1	179	Switch Triggler	1
148	Screw ST4X14	2	180	Upper Handle	1
149	Screw M5X30	4	181	Screw M5X60	1
150	Connect Wire (1x2C)	1	182	Handle	1
151	Screw	1	183	Screw ST5X60	2
152	Connect Bar	1	184	Cable	1
153	Screw	1	185	Cable Spacer	2
154	Screw M6X25	1	186	Cable clamp	1
155	Fixed Cover	1	187	Vise clamp	1
156	Rivet 5*12	4	188	Screw	1
157	Guard scale board	1	189	Vise Handle	1
158	Sheath of Blade Cover	1	190	Connect Bar	1
159	Clip of Bearing	1	191	Stand Bar	1
160	Guide Wheel	1	192	Wrench	1
161	Guide Bushing	1	193	Dust Bag	1

ASSEMBLY DIAGRAM

