

PARTS LIST

No.	Description	No.	Description
1	Right head cover	9	Dust extraction outlet
2	Left head cover	10	Hex key
3	Lower guard	11	Motor
4	Housing	12	Rear cover
5	Push rod	13	Saw blade(not included)
6	Switch	14	Aluminum base plate
7	Support	15	Guide bar
8	Battery pack(not included)		

ASSEMBLY DIAGRAM

