

PARTS LIST

No.	Description	No.	Description
1	Self tapping screw 4×20	15	Motor gear
2	Aluminum head shell	16	Rotor
3	T-shaped shaft gasket/3602	17	Back cover
4	T-shaped output shaft	18	Self tapping screw 3×16
5	O-ring	19	Forward and reverse rotation lever
6	Impact block component	20	Switch bracket
7	Planet gear	21	Stator
8	Cylindrical pin	22	Switch
9	Support pin gasket	23	Lamp panel+lampshade
10	Internal gear ring	24	Controller+switch plug
11	Deep groove ball bearing	25	Housing
12	Self tapping screw 3×14	26	Left and right footboards
13	O-ring 4.8×1.9	27	Self tapping screw 3×12
14	Head shell end cap		

ASSEMBLY DIAGRAM

