

PART LIST

No.	Description	Qty	No.	Description	Qty
1	Saw blade	1	26	Dust catcher cover	1
2	Blade clamp lever ass'y	1	27	Dust catcher	1
3	Reciprocating lever reposition spring	1	28	Tool knob	1
4	Reciprocating lever reset sleeve	1	29	Speed regulating knob spring	1
5	Top slide guide plate	1	30	Steel ball $\phi 3.5$	1
6	Decentration shaft sleeve	1	31	lifting adjuster shaft	1
7	Circlip $\phi 8$	1	32	Screw st3 $\times$ 10	1
8	Wear reducer	1	33	Blow crumbs baffle	1
9	Gear	1	34	Blow crumbs switch	1
10	Balance block	1	35	Holder pin $\phi 4 \times 22$	1
11	Knife brace	1	36	Guide wheel support assembly	1
12	Needle bearing k081108	2	37	Switch	1
13	Upper slide locating pin ϕ	1	38	Screw 4.2 $\times$ 16	12
14	center support assembly	1	39	Right housing	1
15	Calibration block	1	40	Screw m5	1
16	Bearing 6000-2rsfd	1	41	Washer $\phi 5.2 \times 12 \times 1$	1
17	Rotor	1	42	Spanner	1
18	Bearing 627-2z	1	43	Floor lock block	2
19	Stator	1	44	Base plate	1
20	Steel wire	1	45	Aluminum baseplate	1
21	Left housing	1	46	Bottom reinforcing plate	1
22	Speed control knob	1	47	Screw m4 $\times$ 8	6
23	Controller component	1	48	Bottom plate	1
24	Gummed highland barley paper	1	49	Screw m5 $\times$ 30	1
25	Wokin connector	1			

ASSEMBLY DIAGRAM

