


PARTS LIST(CORDLESS DRILL)

No.	Description	No.	Description
1	Inverted screw	11	Speed Button
2	chuck	12	Shell
3	Torque sleeve	13	Tapping Screw
4	Gearbox	14	Battery Pack
5	Motor Gear	15	Switch Assembly
6	Machine screw	16	Belt Clip
7	Motor	17	Machine screw
8	tuning fork	18	Magnet Ring
9	Handspike	19	Heat-shrink Tube
10	Variable Steel		

ASSEMBLY DIAGRAM(CORDLESS DRILL)



PARTS LIST(CORDLESS IMPACT DRIVER)

No.	Description	No.	Description
1	Tapping Screw	13	Planet gear
2	Rubber sleeve	14	Gear pin
3	circlip	15	gasket
4	Quick change gasket	16	deep groove ball bearing
5	Quick change spring	17	ring gear
6	Quick change sleeve	18	Machine screw
7	Al head shell	19	MOTOR COVER
8	Output shaft sleeve	20	Motor
9	Quick change of steel ball	21	BACK SHELL
10	Output shaft	22	Switch Assembly
11	gasket	23	Handspike
12	Impact component	24	Shell
12-1	impact block	25	Tapping Screw
12-2	steel ball	26	Stents / BUFFLE / PCB
12-3	gasket	27	Transparent Cover
12-4	spring	28	Battery Pack
12-5	Central output shaft	29	Belt Clip
12-6	steel ball	30	Machine screw

ASSEMBLY DIAGRAM(CORDLESS IMPACT DRIVER)

