

PART LIST

No.	Description	Qty
1	anti-clamp steel wire	1
2	Support Assembly	1
3	5# Gearbox Assembly	1
4	Machine screw	2
5	Motor Cover	1
6	Tapping Screw	3
7	Adapter block	1
8	Motor	1
9	BOTTOM RUBBLE PAD	2
10	ANVIL RUBBLE PAD	2
11	Rubber gasket	1
12	Shell	1
13	spanner	1
14	Tapping Screw	14
15	rubber buffer	1
16	Damping connecting block	1
17	Handspike	1
18	spring	1
19	back cover	1
20	Switch Assembly	1
21	PLATE	1
22	Machine screw	1
23	Magnetic ring	2
24	shrink-fit hose	2

ASSEMBLY DIAGRAM

