

PARTS LIST

No.	Description	Qty	No.	Description	Qty
1	Swing frame spring / blackening	1	27	Wire guard	1
2	Reciprocating rod assembly	1	28	Cylindrical pin Ø4*Ø25.8	1
3	Needle roller bearing / Split 061208	1	29	Lift knife shelf assembly	1
4	Retaining ring for Ø6 shaft / blackened	1	30	Interposition/both feet	1
5	Gasket Ø6.2*Ø13*0.5	1	31	Left footl	1
6	Large gear component with 48 teeth	1	32	Controller component	1
7	Counterbalance / blackening	1	33	Rubber column	2
8	Needle roller bearing K081217	1	34	Vacuum hose	1
9	Gasket Ø8.3XØ40X0.5	1	35	Right footl	1
10	Lift the cutting board	1	36	Positioning plate / 65D / white zinc plating	1
11	Center bracket assembly	1	37	Base plate/flash silver	1
12	Cylindrical pin 5*20	1	38	Hex socket screw	2
13	Deep groove ball bearing 6000-2RS	1	39	Fixed plate/electrophoresis	1
14	Rotor Ø48*25	1	40	Cross countersunk head screw	6
15	Deep groove ball bearing 626-2RS	1	41	Pressure plate 65/white zinc plating	1
16	Stator Ø48*25	1	42	Hex socket screw	2
17	Right casing	1	43	Explosion-proof board/transparent	1
18	Bearing housing	2	44	Base plate protective cover	1
19	Cylindrical pin Ø3*13	4	45	Guide ruler	1
20	Positioning block	2	46	Left casing	1
21	Pull button spring / blackening	1	47	Lift pin Ø6*31/blackened	1
22	Switch toggle button	1	48	Lift the knife and press the button	1
23	Cross pan head self-tapping screw (pointed head)	16	49	Compression spring cap Ø3.2*Ø4.2*6.8	1
24	Switch/with dust cap	1	50	Compression spring cap / blackened	1
25	Switch spring / blackened	1	51	Transparent cover/Transparent	1
26	Toggle button	1	52	Hexagonal wrench (M4)	1

ASSEMBLY DIAGRAM

