

PARTS LIST

No.	Description	Qty
1	Stator Ø48*20 (with controller)/20V	1
2	Deep groove ball bearing 626-2RS	1
3	Rotor Ø48*20/20V	1
4	Saw frame / Electrophoresis	1
5	Pan head screw with cross head/with spring washer	8
6	Cross pan head self-tapping screw (pointed head)	13
7	Deep groove ball bearing 609-2RS	1
8	Box	1
9	Gasket Ø8.3XØ40X0.5	1
10	Needle roller bearing K081217	1
11	MDJ47 tooth wheel assembly/with eccentric disc	1
12	Counterweight	1
13	Gasket Ø6.2*Ø13*0.5	1
14	Retaining ring for Ø6 shaft / blackened	1
15	Needle roller bearing/ Split 061208	1
16	Oil seal gasket	1
17	Right casing	1
18	Press plate/blackening	1
19	Reciprocating rod assembly/with rubber block	1
20	Switch assembly/DD14/black	1
21	Switch lever	1
22	Cross countersunk head screw	4
23	Limit plate/blackening	1
24	Upper cover	1
25	Left casing	1
26	Left foot	1
27	Intervention/both feet	1
28	Controller	1
29	Right foot	1

ASSEMBLY DIAGRAM

