

PARTS LIST

No.	Description	Qty
1	Collet Set	1
2	Dust cover	1
3	Rubber sleeve	1
4	Gear Box	1
5	Screw ST4.2*30	4
6	Spindle	1
7	Bearing 6001	1
8	Circlip 12	1
9	Bearing 6200	1
10	Elastic Retaining Ring 30	1
11	Middle Aluminum Cover	1
12	Bearing 608	1
13	Elastic Retaining Ring 22	1
26	Connet Pole	1
25	Lock Spring	1
23	Rotor Assy	1
14	Bearing 607	1
15	Switch Push Button	1
16	Switch Pull	1
17	Controller component	1
18	Right Housing	1
19	Gear power display button	1
20	Screw ST3.5*16	5
21	Switch	1
22	Air filter cover	2
24	Left Housing	1
27	Pin	1
28	Spanner	1

ASSEMBLY DIAGRAM

