

PARTS LIST

No.	Description	Qty
1	Foot plate	1
2	Controller component	1
3	Hexagon socket screw lock washer combination	1
4	Main component	1
5	Left and right casings	1
6	Decorative cover	1
7	Toggle button	1
8	Switch return spring	1
9	Lower knife holder	1
10	Blade	1
11	Pin-type oscillating tooth assembly	1
12	Hexagon socket screw M8X1	1
13	Gearbox cover	1
14	Knob cover	1
15	External hexagonal socket wrench	1
16	Hex key	1

ASSEMBLY DIAGRAM

