

PARTS LIST

No.	Description	Qty
1	Foot plate	1
2	Controller component	1
3	Hexagon socket head cap screw M5X14	1
4	Screen blockage	1
5	Main component	1
6	Left and right casings	1
7	Decorative cover	1
8	Toggle button	1
9	Switch return spring	1
10	Lower knife holder	1
11	Blade	1
12	Gear-oscillating assembly	1
13	Hexagon socket screw M8X1	1
14	Gearbox cover	1
15	External hexagonal socket wrench	1
16	Hex key	1

ASSEMBLY DIAGRAM

