PARTS LIST

No.	Description	Qty	No.	Description	Qty
1	Polishing Pad	1	25	608 Bearing	1
2	Screw M4×35	4	26	Headshell Protective Cover	1
3	Unbalanced Block Guard	1	27	screw ST4.2*35	1
4	Hole with elastic retaining ring	1	28	Head capsule	1
5	Secondary Output Shaft	1	29	Hexagonal Nut	1
6	6901Z Bearing	2	30	Pinion gear	1
7	Circle of Distance	1	31	608 RS Bearing	1
8	Shaft Elastic Retaining Ring	1	32	Rectangular loop	1
9	Eccentric block	1	33	Middle Cover	1
10	Output shaft	1	34	Rotor	1
11	Semicircular key	1	35	607 Bearing	1
12	Dust cover	1	36	Switch Push Block	1
13	Screw M4*14	4	37	Switch lever	1
14	Screw M4×18	2	38	Stator + Controller	1
15	Front cover	1	39	Gear Power Display Button	1
16	6201 Bearing	1	40	Screw ST3.5*16 Flat tail Black	5
17	Hole with elastic retaining ring	1	41	Right casing	1
18	Secondary large gear	1	42	Switch	1
19	Shaft Retaining Ring	1	43	Pin	1
20	Needle roller bearing	1	44	Left housing	1
21	Screw ST4.2*30	2	45	Side handle	1
22	629 Bearing	1	46	Wool Wheel	1
23	Pinion Shaft	1	47	Wrench	1
24	Large gear	1			

ASSEMBLY DIAGRAM

