

PARTS LIST

No.	Description	Qty
1	Cross head counterclockwise screw M6*20	1
2	13mm metal ratchet chuck	4
3	Torx self-tapping screw M3*13	4
4	Torque cup iron sheet	1
5	Torque cup	1
6	Torx self-tapping screw M3*13	4
7	Front decorative cover	1
8	Impact gearbox assembly	1
9	Speed control gear shift	1
10	Twist wire	1
11	Motor tooth	1
12	4815 Stator	1
13	4815 Rotor	1
26	Controller	1
25	Switch	1
23	Lighting lamp	
14	Counter-sunk screw M3*8	1
15	Left casing	1
16	Grip decorative piece (left)	1
17	Grip decorative piece (right)	1
18	Right casing	1
19	Rear decorative cover	1
20	Torx self-tapping screw M3*13	4
21	Positive and negative rotation toggle	1
22	Lampshade	1
24	Control panel	1
27	Switch pin	1

ASSEMBLY DIAGRAM

