

PARTS LIST

No.	Description	Qty	No.	Description	Qty
1	Self tapping screw 4 * 20	4	17	Back cover	1
2	Aluminum head shell	1	18	Self tapping screw 3 * 16	5
3	T-shaped shaft gasket/3602	1	19	Forward and reverse rotation lever	1
4	T-type dual-purpose output shaft	1	20	Switch bracket	1
5	O-ring	1	21	Stator	1
6	Impact block component	1	22	Switch	1
7	Planet gear	3	23	Lamp panel+lampshade	1
8	Cylindrical pin	3	24	Controller+switch plug	1
9	Support pin gasket	1	25	Housing	1
10	Internal gear ring	1	26	Left and right footboards	1
11	Deep groove ball bearing	1	27	Self tapping screw 3 * 12	1
12	Self tapping screw 3 * 14	7	28	Belt	1
13	O-ring 4.8 * 1.9	1	29	Screw M4*10	1
14	Head shell end cap	1	30	Pin	1
15	Motor gear	1	31	O-ring 28 * 3.1	1
16	Rotor	1			

ASSEMBLY DIAGRAM

