

PARTS LIST

No.	Description	Qty	No.	Description	Qty
1	Rubber head cover	1	19	O-ring	1
2	Steel Cable Baffle Ring	1	20	Head shell end cap	1
3	Bush liner	1	21	Stator	1
4	Pressure spring	1	22	Motor gear	1
5	Sleeve	1	23	Rotor	1
6	Steel ball	2	24	Switch	1
7	Aluminum head case	1	25	Control board	1
8	O-ring	1	26	Housing	1
9	Bearing	3	27	Lampshade	2
10	Bearing washer	2	28	Forward and reverse rotation lever	1
11	Hole circlip	1	29	Switch bracket	1
12	Output shaft washer	1	30	Switch Pin	1
13	T output shaft	1	31	Back cover	1
14	Impact block assembly	1	32	Screw	10
15	Planet gear	3	33	Belt	1
16	Pin	3	34	Screw	1
17	Support pin gasket	1	35	Lampshade	1
18	Internal gear ring	1	36	Left and right footboards	1

ASSEMBLY DIAGRAM

