

PARTS LIST

No.	Description	Qty	No.	Description	Qty
1	Three-in-one cross head screw M4×14	4	17	Left casing	1
2	125 round sand disc, black	1	18	Adapter sleeve	1
3	Base plate positioning sleeve	1	19	M4×8 countersunk head screw	2
4	Rubber sleeve	1	20	Middle iron sheet	1
5	Dust collection ring	1	21	785 motor	1
6	Cross recessed screw M4×12 (painted)	1	22	Switch (ship-shaped dustproof)	1
7	Flat gasket Ø4×Ø20×2	1	23	18AWG lead wire, red	1
8	Bearing 6002-2RS	1	24	18AWG lead wire, red	1
9	Flat pad Ø15×Ø26×0.5	1	25	Governor	1
10	Bearing locating seat	1	26	Right casing	1
11	Eccentric block	1	27	Cross recessed pan head screw self-tapping ST4×16	8
12	Counterweight iron plate	1	28	Battery pack foot plate	1
13	Plastic fan blades	1	29	Interposing	1
14	Flat pad Ø9×Ø21×0.5	1	30	Under the foot plate of the Jieai battery pack	1
15	Bearing 629-2RS	1	31	Vacuum cleaner adapter	1
16	Nameplate fastener	2	32	Dust collection box assembly	1

ASSEMBLY DIAGRAM

