

PARTS LIST

No.	Description	Qty	No.	Description	Qty
1	Reverse threaded hexagon socket screw	1	27	Vacuum adapter sleeve	1
2	Flat washer	3	28	Square neck bolt	1
3	Press plate on saw blade	1	29	Main spindle self-locking button	1
4	Saw blade	1	30	Self-locking spring for main shaft	1
5	Saw blade lower pressing plate	1	31	Self-locking iron sheet for main shaft	1
6	Cross head self-tapping screw	13	32	Screw	1
7	Cross countersunk head self-tapping screw	3	33	Lower shell	1
8	Front cover	1	34	Lower foot plate	1
9	Bearing	1	35	Pin	1
10	Output shaft	1	36	Self-locking spring for switch	1
11	Large gear	1	37	Self-locking switch button	1
12	Bearing	1	38	Switch	1
13	Pan head screw	1	39	Led lampshade	1
14	Protective cover shock absorber ring	1	40	Pinion	1
15	Base plate connecting screw	1	41	Motor	1
16	Aluminum head shell	1	42	Upper shell	1
17	Iron base plate	1	43	Upper foot plate	1
18	Lock nut	1	44	Rubber column	1
19	Square neck bolt	1	45	Depth adjustment link rod	1
20	Wing nut	1	46	Depth adjustment wrench	1
21	Butterfly screw	1	47	Cross head self-tapping screw	2
22	Guide ruler fixing spring	1	48	Rear cover	1
23	Elastic retaining ring for shaft	1	49	Label decorative cover	1
24	Movable protective cover	1	50	Hex wrench	1
25	Protective cover reset spring	1	51	Guide rule	1
26	Pan head screw				

ASSEMBLY DIAGRAM

