

## PARTS LIST

| No.   | Description       | Qty |
|-------|-------------------|-----|
| 1-23  | Swing assembly    | 1   |
| 24-33 | Cylinder assembly | 1   |
| 34    | Casing            | 1   |
| 35    | Circlip           | 1   |
| 36    | Function knob     | 1   |
| 37    | Motor             | 1   |
| 38    | Direction switch  | 1   |
| 39    | Switch            | 1   |
| 40    | Rubber plug       | 2   |
| 41    | Connect foot      | 1   |
| 42    | Controller        | 1   |
| 43    | Left oil seal     | 1   |
| 44    | Needle bearing    | 1   |
| 45    | Needle bearing h  | 1   |
| 46    | Right oil seal    | 1   |
| 47    | Screw             | 12  |

### ASSEMBLY DIAGRAM

