

PARTS LIST

No.	Description	Qty	No.	Description	Qty
1	Rubber Foot	4	44	Cap of Brush Holder	2
2	Hexagon Nut(C	1	45	Carbon Brush	2
3	Base	1	46	Brush Holder	2
4	Hexagon Nut	1	47	Plastic Housing	1
5	Big Washer (A	1	48	Locking Pin	1
6	Small Clamping Plate	1	49	Spring of Lock Pin	1
7	Screw	1	50	Wool Felt	1
8	Hatch Pin	1	52	Bearing	1
9	Vice Stand	1	51	Bearing	1
10	Column Pin	1	53	Cable Wire	1
11	Speed Nut	1	54	Stator	1
12	Flat Washer (C	1	55	Cross Screw	2
12	Flat Washer (C	4	56	Anti-wind Ring	1
13	Standard Spring Washer	2	57	Rotor	1
14	Hexagon Bolt	2	58	Bearing	1
15	Column Pin	1	59	Cross Screw	2
16	Scale Plate	1	60	Cross Screw	1
17	Flat Washer (C	2	61	Gear Pad	1
18	Standard Spring Washer	2	62	Aluminum Housing	1
19	Hexagon Bolt	2	63	Protective Cover	1
20	Hexagon Bolt	1	64	Cross Screw	4
21	Cap of Height Limited Pin	1	65	Active Cover	1
22	Type "O" Ring	1	66	Screw	2
23	Height Limited Pin	1	67	Spring Washer	1
24	Limited Bushing	1	68	Gear	1
25	Adjusting Stand	1	69	Bearing Holder	1
26	Hexagon Nut	1	70	Bearing	1
27	Hexagon Screw	1	71	Flat Washer (A	1
28	Support Bracket	1	72	Spindle	1
29	Cross Screw	2	73	Lock Catch	3
30	Standard Spring Washer	2	74	Lock Pin	3
30	Standard Spring Washer	9	75	Clamp	2
31	Flat Washer (C	2	76	Cutting Wheel	1
31	Flat Washer (C	7	77	Cord Armor	1
32	Hexagon Nut	1	78	Small Clamp	1
33	Dust Board	1	79	Hexagon Bolt	1
34	Flat Washer (C	4	80	Hexagon Nut(C	3
34	Flat Washer (C	1	81	Right Handle	1
35	Standard Spring Washer	4	82	Switch	1
35	Standard Spring Washer	1	83	Cord Anchorage	1
36	Hexagon Screw	1	84	Cross Screw	2
37	Big Spring	1	85	Left Handle	1
38	Circumgyrate Pin	1	86	Cross Screw	6
39	Circumgyrate Pin Cover	1	87	Cross Screw	5
40	Cross Screw	2	88	Hexagon Nut	2
41	Cross Screw	2	89	Protector	1
42	Rear Cover	1	90	Cross Screw	2
43	Cross Screw	3			

ASSEMBLY DIAGRAM

