PARTS LIST

No.	Description	Qty	No.	Description	Qty
1	Rubber Foot	3	51	Bearing 6000	1
2	Hexagon Nut M8	3	52	Bearing 6200	1
3	Base	1	53	Cable Wire	1
4	Nut M8	1	54	Stator	1
5	Big Washer Φ20xΦ8x2	1	55	Cross Screw ST5X70	2
6	Small Clamping Plate	1	56	Anti-wind Ring	1
7	Screw	1	57	Rotor	1
8	Hatch Pin 2.5*15	1	58	Bearing 6202	1
9	Vice Stand	1	59	Cross Screw ST5X45	2
10	Column Pin 6.4*30	1	60	Cross Screw M5X12	2
11	Speed Nut	1	61	Gear Pad	1
12	Flat Washer Φ16xΦ8x1	3	62	Rocker arm	1
13	Standard Spring Washer 8	2	63	Protective Cover	1
14	Hexagon Bolt M8X25	2	64	Protecter	1
15	Column Pin	1	65	Active Cover	1
16	Scale Plate	1	66	Screw	2
17	Flat Washer	2	67	Spring Washer 20	1
18	Standard Spring Washer 10	2	68	Gear	1
19	Hexagon Bolt M10X20	2	69	Bearing Holder	1
20	Hexagon Bolt	1	70	Bearing 6204	1
21	Cap of Height Limited Pin	1	71	Flat key 5X5X16	1
22	Type "O" Ring 5	1	72	Spindle	1
23	Height Limited Pin	1	73	Lock Catch	3
26	Hexagon Nut M5	2	74	Lock Pin	3
27	Hexagon Screw	1	75	Clamp	2
30	Standard Spring Washer 5	6	76	Cutting Wheel	1
31	Flat Washer Φ10xΦ5x0.5	4	77	Cord Armor	1
32	Hexagon Nut M6	1	78	Small Clamp	1
33	Dust Board	1	79	Hexagon Bolt level8.8 M10X25	1
34	Flat Washer Φ14xΦ6x1	5	81	Right Handle	1
35	Standard Spring Washer 6	5	82	Switch	1
36	Hexagon Screw M6X18	5	83	Cord Anchorage	1
37	Big Spring	1	84	Cross Screw ST4X14	2
38	Circumgyrate Pin	1	85	Left Handle	1
40	Cross Screw M5X10	1	86	Cross Screw ST4X16	6
41	Cross Screw ST4X12	3	87	Cross Screw M5X28	4
42	Rear Cover	1	89	Open retaining ring 6	1
43	Cross Screw	2	90	Rock cap	1
44	Cap of Brush Holder	2	91	Ring 8	1
45	Carbon Brush	2	92	Flat Washer A	3
46	Brush Holder	2	93	Nut M16	1
47	Plastic Housing	1	94	Nut M8	1
48	Locking Pin	1	95	Standard Spring Washer 8	1
49	Spring of Lock Pin	1	96	Cross Screw ST5X30	1
50	Wool Felt Φ11xΦ5.5x2	1			

ASSEMBLY DIAGRAM

