

PARTS LIST

ITEM	ENGLISH DESCRIPTION	Q'TY	ITEM	ENGLISH DESCRIPTION	Q'TY
1	DAMPING WASHER	4	44	SIIDE RULE	1
2	NUT M8	4	45	INSERT M3×6	1
3	BASE	1	46	CROSS RECESS COUNTERSUNK HD SCREW	2
4	HEX. SOC HD CAP SCREW M6×20	4	47	GONIOMETER	1
5	LOWER DOOR LOCK	2	48	ANGLE LOCKING HANDLE KNOB M4×12	1
6	CROSS RECESSED PAN HEAD SCREW M5×8	5	49	CROSS RECESSED PAN HEAD SCREW	1
7	CHIP DISCHARGE PORT	1	50	INDICATOR	1
8	OUTSIDE HEX. BOLT M8×70	1	51	ANGLE LABEL	1
9	INDICATOR	1	52	LOCKING HANDLE FOR TABLE	1
10	FLAT WASHER 4	1	53	ADJUSTING HANDLE KNOB	1
11	CROSS RECESSED PAN HEAD SCREW M4×16	1	54	LOCKING LABEL	1
12	ROUND NUT M8	1	55	PULLEY LABEL	1
13	HEX. SOC HD CAP SCREW M8×12	4	56	ANGLE LABEL	1
14	SPRING WASHER 8	4	57	TENSIONING KNOB	1
15	FLAT WASHER 8	4	58	HANDLE M8×16	1
16	TABLE SUPPORT YL102	1	59	HEX. SOC HD CAP SCREW M6	6
17	ROTATING SLEEVE 45	2	60	LOCK NUT	1
18	FLAT WASHER 8	1	61	LOCKING PLATE	1
19	ANGLE LOCKING KNOB	1	62	SPRING	1
20	MOTOR	1	63	RIP FENCE ST4×10	1
21	FLAT WASHER 6	9	64	CROSS RECESS HEAD SCREW	2
22	LABEL	1	65	RIP FENCE	1
23	PLUG WITH CABLE	1	66	SCREW	1
24	CABLE FLANGE M16	1	67	RIP FENCE LOCKING LEVER 4×16	1
25	HEX. SOC HD CAP SCREW M6×10	5	68	ROLL PIN	1
26	SPRING WASHER 6	6	69	GUIDE FRAME M5×16	1
27	WOOD CHIPS FRAME	1	70	HEX. SOC HD CAP SCREW	1
28	CROSS RECESSED PAN HEAD SCREW M4×8	2	71	GUARD PLATE ST3×10	1
29	SPRING CABLE FLANGE	1	72	CROSS RECESS HEAD SCREW	4
30	ADJUST THE SEAT	1	73	GUIDE FRAME SPRING	1
31	FLAT WASHER 5	8	74	COVER PLATE	1
32	CROSS RECESSED PAN HEAD SCREW M5×12	6	75	LOCKING PLATE	1
33	ADJUSTING HANDLE KNOB	1	76	GUIDE PLATE	1
34	HEX. SOC SET SCREW M4×4	1	77	BEARING SPINDLE 5×14	1
35	ADJUSTING GEAR	1	78	ROLL PIN	4
36	FLAT WASHER 8	1	79	HEX. SOC SET SCREW M5×10	4
37	LOCKING HANDLE KNOB	1	80	UPPER SAW BLADE GUIDE	1
38	HEX. SOC HD CAP SCREW M5×10	3	81	BLADE BEARING 606RS	2
39	ANGLE ADJUSTING HANDLE KNOB	1	82	BLADE BEARING SCREW	2
40	THUMBS SCREW M6×25	1	83	NUT M10	1
41	OUTSIDE HEX. BOLT M6	2	84	FLAT WASHER 10	1
42	NUT	5	85	BLADE GUARD	1
43	TABLE	1			

PARTS LIST

ITEM	ENGLISH DESCRIPTION	Q'TY
86	UPPER BLADE PULLEY SPINDLE	2
87	BEARING 6000RS	11
88	CIRCLIP FOR HOLE 26	2
89	UPPER BLADE PULLEY	1
90	FRICTION WASHER	2
91	CIRCLIP FOR BEARING 10	1
92	BLADE	1
93	UPPER DOOR	1
94	LOCKING RING	2
95	MAIN LABEL	1
96	ARROW LABEL	1
97	CROSS RECESSED PAN HEAD SCREW M6×12	4
98	CIRCLIP FOR BEARING 8	2
99	BEARING PIN 8×70	1
100	ADJUSTING SPRING	1
101	WELDMENTS	1
102	LOCKING FRAME	1
103	ADJUSTING SCREW	1
104	PUSH STICK SCREW M6	1
105	PUSH STICK	1
106	FIXED PLATE	1
107	SWITCH BOX	1
108	SWITCH	1
109	TOOTH LOCK WASHER 4	1
110	SPRING WASHER 4	1
111	ELECTRICAL GROUNDING LABEL	1
112	CROSS RECESSED PAN HEAD SCREW M4×6	1
113	BRUSH RING	1
114	BRUSH	1
115	BRUSH SCREW	1
116	OUTSIDE HEX. BOLT M8×40	1
117	LOWER FIXED PLATE	1
118	LOWER BEARING SPINDLE	1
119	LOWER SAW BLADE GUIDE	1
120	FLAT KEY 5×5×16	1
121	LOWER BLADE PULLEY	1
122	BIG FLAT WASHER 6	1
123	SPEED LABEL	1
124	LOWER DOOR	1
125	LABEL	1
126	OPEN END WRENCH S10	1
127	HEXAGON BAR WRENCH S2.5	1
128	HEXAGON BAR WRENCH S3	1
129	HEXAGON BAR WRENCH S4	1

ASSEMBLY DIAGRAM

