


ASSEMBLY DIAGRAM & PARTS LIST



PARTS LIST

Part	Description	Qty	Part	Description	Qty
1	Fan cover	1	17	Sealing ring	1
2	Screw	4	18	Screw M6x14	4
3	Hex nuts M4x112	4	19	Screw M6x35	3
4	Fan	1	20	Impeller	1
5	Back cover	1	21	Pump Body	1
6	Bearing 6201	1	22	Air screw	1
7	Rotor	1	23	Dust cover	1
8	Pin	1	24	Pressure tank	1
9	Bearing 6201	1	25	connector	1
10	O-ring	1	26	Pressure switch	1
11	Mechanical Seal 301-12	1	27	Coil	1
12	Circlip	1	28	Screw M4x15	2
13	Screw M8x25	2	29	Terminal Box	1
14	Inlet	1	30	Capacitor	1
15	Check valve	1	31	Pump Body	1
16	Pump Cover	1			