

Parts List

S.N.	Part	Qty
1	BASE	1
2	COLUMN FLANGE	1
3	SPRING WASHER	4
4	OUTSIDE HEX. BOLT	4
5	RACK	1
6	COLUMN	1
7	HEX. SOC SET SCREW	2
8	COLLAR RACK	1
9	HANDLE TIP	3
10	HANDLE	3
11	HANDLE SEAT	1
12	DIAL SCALE	1
13	WING KNOB	1
14	ROLL PIN	1
15	GEAR SHAFT	1
16	WARNING LABEL	1
17	INDICATOR	1
18	ROLL PIN	1
19	ROLL PIN	2
20	WING KNOB	1
21	HANDLE BELT TENSION	1
22	CIRCLIP FOR BEARING	1
23	CIRCLIP FOR BEARING	1
24	SLIP SHAFT	1
25	ADJUSTING SHAFT	1
26	FLAT WASHER	4
27	OUTSIDE HEX. BOLT	4
28	FLAT WASHER	8
29	MOTOR CONNECTION PLATE	1
30	NUT	2
31	OUTSIDE HEX. BOLT	4
32	MOTOR PULLEY	1
33	MOTOR	1
34	SPRING WASHER	2
35	NUT	5
36	CAM PIN	1
37	CAM	1
38	DAMPING WASHER	4
39	SPEED LABEL	1
40	CROSS RECESSED PAN HEAD SCREW	1
41	FLAT WASHER	4
42	CROSS RECESSED PAN HEAD SCREW	1
43	FLAT WASHER	6
44	PULLEY COVER	1
45	CROSS RECESSED PAN HEAD SCREW	5
47	SPRING WASHER	2
48	NUT	2
49	NUT	1
50	SPRING WASHER	1
51	MICRO SWITCH PRESSING CLAW	1
52	ECCENTRIC SHAFT	1
53	MIDDLE PULLEY	1
54	BEARING	2

S.N.	Part	Qty
55	CIRCLIP FOR HOLE	1
56	BELT	1
57	LABEL	1
58	BELT	1
59	SPINDLE PULLEY	1
60	CIRCLIP FOR HOLE	2
61	KEYWAY SPINDLE	1
62	BEARING	2
63	NUT	2
64	CORD CLAMP	2
65	PROTECTOR RING	1
66	FLAT WASHER	1
67	CROSS RECESSED PAN HEAD SCREW	2
68	PLUG WITH CABLE	1
69	THREAD DRAWING	1
70	CROSS RECESS HEAD SCREW	2
71	SWITCH	1
72	LABEL	1
73	CROSS RECESS HEAD SCREW	2
74	TOOTH LOCK WASHER	2
75	GROUNDED PARTS	2
76	HEX. SOC SET SCREW	3
77	THIN NUT	2
78	SPRING	1
79	SPRING COVER	1
80	A WORD HEAD SCREW	1
81	LABEL	1
82	HOUSING	1
83	CRANK	1
84	OUTSIDE HEX BOLT	1
85	CIRCLIP FOR BEARING	1
86	WORM	1
87	WORM GEAR	1
88	TABLE SUPPORT	1
89	WORM PIN	1
90	ANGLE LABEL	1
91	LOCKING HANDLE	1
92	LOCKING HANDLE	1
93	SPRING WASHER	1
94	OUTSIDE HEX. BOLT	1
95	TABLE ARM	1
96	WORKING TABLE	1
97	CIRCLIP FOR BEARING	1
98	BEARING	1
99	SPINDLE SOCKET	1
100	MAIN SPINDLE	1
101	BEARING	1
102	WASHER	1
103	TAPER SPINDLE	1
104	CHUCK	1
106	HEXAGON BAR WRENCH	1
107	THICK BRAKE IRON	1

Assembly Diagram

