

PARTS LIST

NO.	Description	Qty	NO.	Description	Qty
1	Container	1	23	O-ring for spray gun seat	1
2	Airproof washer	1	24	Motor house	1
3	Sucker	1	25	Motor	1
4	Terminal block	1	26	Motor airproof ring	1
5	Capacitor	1	27	Motor cover	1
6	Switch	1	28	Filter net	1
7	Cord Limiter	1	29	House cover	1
8	Screw	5	30	Spring	1
9	Label	2	31	Button	1
10	housing	1	32	Cord & plug	1
11	Spring	1	33	Cord sleeve	1
12	Switch pole	1	34	Screw	2
13	Adjust button	1	35	Cord clamp	1
14	Trigger frame	1	36	housing	1
15	Pin	1	37	O-ring	2
16	Nut	1	38	O-ring	2
17	Change nozzle	1	39	Valve needle spring	1
18	Fixed nozzle	1	40	Gun stopper	1
19	Valve needle tip	1	41	Internal wire	1
20	Valve needle spring	1	42	Trigger	1
21	valve needle tail	1	43	Soft grip	4
22	Spray gun seat	1			

ASSEMBLY DIAGRAM

