

PARTS LIST

Part	Description	Qty.	Part	Description	Qty.
1	Base Plate	1	27	Screw ST4.2X13	3
2	Screw M4X8	4	28	Cable 2×0.75×2.0m	1
3	Fender	1	29	Cable Protector	1
4	Flat Washer 5	2	30	Cable Clamp	1
5	Fixing Knob	1	31	Electric Ring	2
6	Base Fixing Button ☒	2	32	Brush Holder	2
7	Spring spring washer 6	2	33	Carbon Brush	2
8	Flat Washer 6	2	34	Brush Cover	2
9	Adjustment Block	1	35	Stator	1
10	Base Fixing Button ☒	1	36	Bearing Bush	1
11	Base Position Block	1	37	Bearing 607 2RS	1
12	Screw M5X10	1	38	Ring PA6-GF30	1
13	Depth Adjustment Block	1	39	Rotor	1
14	Nut M5	1	40	Ring 65Mn	1
15	Position Lock Mast	1	41	Scrwe ST4.2×65-F	2
16	Plastic Gear	1	42	Housing	1
17	Fixing Pole	1	43	Spec.Label	1
18	Dust Guard	1	44	Switch	1
19	Clamp Nut	1	45	Label	1
20	Collet	1	46	Rear Cover	1
21	Anti-dust Clamp	1	47	Nut M6X15	1
22	Housing	1	48	Fixing Bracket	1
23	Screw ST4.2X35F	4	49	Guide Base	1
24	Depth Indicator	1	50	Position Fixing Knob	1
25	Bearing 6002	1	51	Spanner 10	1
26	Bearing Clamp	1	52	Spanner 17	1

ASSEMBLY DIAGRAM

