

5. PARTS LIST AND DIAGRAM

No.	Name
1&8&9	Blower assembly
2	Label
3	Front cover
4	Screw nut
5	Flat gasket
6	Fan
7&19	Left & right housing
10	Bearing
11	Screw
12&13	Rotor
14	Screw
15	Power socket+Terminal
16	Switch
17	Stotor
20	Brush cover
21	Carbon brush
22	Brush holder
23	Cord&plug assembly
24	Screw
25	Screw

