

PARTS LIST

NO.	Part name	QTY	NO.	Part name	QTY
1	Upper ressure plate	1	24	Bearings	1
2	Grinding wheel	1	25	Bearing sleeve with disc	1
3	Lower pressure plate	1	26	Windshield	1
4	Grinding wheel cover	1	27	stator	1
5	Output shaft	1	28	Housing	1
6	Dust seal	1	29	Switch button	1
7	Cross recessed pan head screws	4	30	Coil Spring	2
8	Front cover	1	31	Carbon Brush	2
9	Bearings	1	32	Cross recessed self tapping screws	4
10	Elastic retaining ring for hole	1	33	Brush holder	2
11	Big gear	1	34	switch	1
12	Needle Roller Bearings	1	36	Wire clamp	1
13	Cross recessed pan head self tapping screws	4	37	Cross recessed self tapping screws	2
14	Self-locking pin	1	38	Sheath	1
15	Self-locking spring	1	40	Switch push rod	1
16	Self-locking cap	1	41	Rear cover	1
17	Head Shell	1	42	Cable plug	1
18	Nuts	1	43	Cross recessed self tapping screws	1
19	Small gear	1	44	Auxiliary handle	1
20	Bearings	1	45	wrench	1
21	Elastic retaining ring for hole	1			
22	Rotor	1			
23	Creepage retaining ring	1			

ASSEMBLY DIAGRAM

