


ASSEMBLY DIAGRAM



PARTS LIST

Part	Description	Part	Description
1	Sealing ring 13*3	14	Crosshead screw
2	Air screw M10	15	Capacitor (insert)16μF
3	Pump body	16	Cylinder
4	Nut M10	17	Outlet
5	Impeller	18	Flat key pin 4*12
6	External ring	19	Rotor
7	Oil sealing 301-14	20	Bearing 6202
8	Sealing ring 165*3.1	21	Wave gasket 202
9	Connector	22	Rear cover
10	Outer hexagonal screw M8*25	23	Fan
11	Outer hexagonal screw M5*22	24	Fan cover
12	Connection post	25	Stator
13	Terminal box		