

PARTS LIST

Part	Description	Qty
1	handle screw 4x14	2
2	308 handle	1
3	switch(2P)	1
4	Data label	1
5	308top cover	1
6	Motor cover	1
7	screw 4x14	2
8	Power cord press board and screw4x16	1
9	Power cord 5m	1
10	bottom cover	1
11	motor top frame	1
12	202S Motor top sealing ring	1
13	Motor space ring	1
14	SM Motor top sealing ring	1
15	SM24 motor	1
16	safety valve	1
17	Motor bottom sealing ring	1
18	motor below frame	1
19	bottom cover bascket	1
20	bottom cover bascket screw 4x20	6
21	motor noise reduction sponge	1
22	capacitance	1
23	308 clamps	2
24	308 clamps base	2
25	308 clamps handle	2
26	clamp screw 4x14	4
27	308 air-inlet sets sealing ring	1
28	308 air-inlet sets	1
29	air-inlet sets screw 4x14	4
30	308 water outlet cover	1
31	308 water outlet cover sealing ring	1
32	tank	1
33	308 castors	4
34	wheels	4
35	screw 4x14	4
36	1.5m hose	1
37	small nozzle	1
38	foam filter	1
39	Plastic tube	2
40	dry&wet square brush	1
41	Paper dust bag	1
42	Cartridge filter	1

ASSEMBLY DIAGRAM

