

### PARTS LIST

| Part | Description            | Qty | Part | Description               | Qty |
|------|------------------------|-----|------|---------------------------|-----|
| 1    | Crankcase              | 1   | 34   | screw                     | 4   |
| 2    | Crank                  | 1   | 35   | wind scooper              | 1   |
| 3    | Connecting rod         | 1   | 36   | screw                     | 2   |
| 4    | Crank screw            | 1   | 37   | screw                     | 2   |
| 5    | Side cover gasket      | 1   | 38   | Circlip                   | 1   |
| 6    | Side cover             | 1   | 39   | fan blade                 | 1   |
| 7    | Seal ring              | 1   | 40   | backstand                 | 1   |
| 8    | Oil immersion lens     | 1   | 41   | stator                    | 1   |
| 9    | Side cover screw       | 4   | 42   | bearing                   | 1   |
| 10   | Breather               | 2   | 43   | rotor                     | 1   |
| 11   | Circlip                | 1   | 44   | bearing                   | 1   |
| 12   | Piston pin             | 1   | 45   | oil seal                  | 1   |
| 13   | Piston                 | 1   | 46   | screw                     | 8   |
| 14   | Oilring                | 1   | 47   | nut                       | 8   |
| 15   | Cylinder circlip       | 2   | 48   | pressure switch           | 1   |
| 16   | Cylinder gasket        | 1   | 49   | 40pressure gage           | 2   |
| 17   | Cylinder               | 1   | 50   | pressure relief valve     | 1   |
| 18   | Locating pin           | 4   | 51   | globe valve               | 2   |
| 19   | Valve block            | 1   | 52   | pressure regulating valve | 1   |
| 20   | Valve plate gasket     | 1   | 53   | exhaust pipe              | 1   |
| 21   | Valve plate            | 1   | 54   | non-return valve          | 1   |
| 22   | Discharge valve plate  | 1   | 55   | Pressure relief pipe      | 1   |
| 23   | Exhaust pressure plate | 1   | 56   | gasholder                 | 1   |
| 24   | Disc spring washers    | 2   | 57   | nut                       | 2   |
| 25   | Screw                  | 2   | 58   | trundle                   | 2   |
| 26   | Cylinder head gasket   | 1   | 59   | axle                      | 2   |
| 27   | Cylinder head          | 1   | 60   | blowdown valve            | 1   |
| 28   | Cylinder head bolts    | 4   | 61   | Rubber Foot               | 1   |
| 29   | Elbow                  | 1   | 62   | power line                | 1   |
| 30   | Silencer               | 1   | 63   | CE plate                  | 1   |
| 31   | Capacitance            | 1   | 64   | gasket                    | 2   |
| 32   | Crimping cap           | 2   | 65   | deflating valve           | 2   |
| 33   | Spring shim            | 4   | 66   | handle                    | 1   |

### ASSEMBLY DIAGRAM

