

PARTS LIST

NO.	Description	Qty	NO.	Description	Qty
1	Water outlet valve core	1	21	Stainless steel oil chamber cover	1
2	Oulet valve	1	22	Oil chamber	1
3	Upper support	1	23	Sealing ring	1
4	Guide vane	1	24	Stator	1
5	Impeller	1	25	Lower bearing chamber	1
6	Partition	1	26	Leather bowl	1
7	Screw	1	27	Bottom cover	1
8	Upper shaft sleeve	1	28	Circlip	1
9	Intermediate shaft sleeve	1	29	Water outlet	1
10	Pump shaft	1	30	Sealing ring	1
11	Lower shaft sleeve	1	31	Pump barrel	1
12	Hard oil seal	1	32	Stainless steel pressing plate	1
13	Single-sided oil seal	1	33	Stainless steel gusset plate	1
14	Bearing	1	34	Screw	2
15	Rotor	1	35	Filter	1
16	Bearing	1	36	Screw	2
17	Rubber sleeve	1	37	Tumbuckle	4
18	Cable	1	38	Screw	4
19	Four-eye rubber	1	39	Motor barrel	1
20	Inlet	1			

ASSEMBLY DIAGRAM

