


PARTS LIST

NO.	Part name	Qty	NO.	Part name	Qty	NO.	Part name	Qty
1	Straps	1	30	Screw	4	59	Hoop	1
2	Straps	1	31	Canister	1	60	Bolwpipe	1
3	Axis	2	32	Hoop	1	61	Nut	1
4	Clip	11	33	Hoop	1	62	Washer	1
5	Nut	11	34	Oil pipe	1	63	Handle	1
6	Back pad	1	35	Filter cleaner	1	64	Bolt	1
7	Frame carrier	1	36	Fuel tank	1	65	Bolwpipe	1
8	Protective screening	1	37	Lid assy	1	66	Bolwpipe	1
9	Screw	2	38	Chain	1	67	Control box	1
10	Screw	2	39	Back base	1	68	Nut	9
11	Protective screening	1	40	Bolt	4			
12	Bolt	11	41	Plunger	1			
13	Hook houshing a	1	42	Impeller	1			
14	Hook houshing b	1	43	Spring	2			
15	Washer	4	44	Screw	1			
16	Bolt	4	45	Bolt	7			
17	Bolt	2	46	Washer	9			
18	Spring	1	47	Clip	1			
19	Screw	4	48	Screw	3			
20	Cover	2	49	Bolt	6			
21	Bolt	2	50	Front base	1			
22	Loam cake	1	51	Screw	5			
23	Filter element	1	52	Cylinder cover	1			
24	Filter element	1	53	Thermal baffle	1			
25	Lower cover	1	54	Screw	2			
26	Bracket	1	55	Bolt	2			
27	Bracket	1	56	Joint	1			
28	Bracket	1	57	Hoop	1			
29	Bracket	1	58	Hose	1			



PARTS LIST (ENGINE)

NO.	Part name	Qty	NO.	Part name	Qty
1	Bolt	2	38	Piston pin	1
2	Washer	20	39	Piston	1
3	Washer	16	40	Piston ring	1
4	Muffler	1	41	Piston ring	1
5	Muffler gasket	1	42	Gasket	1
6	Washer	2	43	Back crankcase	1
7	Washer	2	44	Ratchet	1
8	Bolt	2	45	Nut	1
9	Washer	8	46	Screw	1
10	Bolt	4	47	Washer	1
11	Cap	1	48	Guide slice	1
12	Spring	1	49	Washer	1
13	Plug	1	50	Start wheel	1
14	Cylindera	1	51	Rope	1
15	Nut	1	52	Pulley	1
16	Washer	1	53	Spring	1
17	Washer	2	54	Case	1
18	Rotor	1	55	Handle	1
19	Seal	2	56	Pack	1
20	Bolt	4	57	Screw	2
21	Front crankcase	1	58	Baffle	1
22	Pin	2	59	Choker	1
23	Bearing	2	60	Cover	1
24	Gasket	1	61	Gasket	1
25	Lgnition coil comp	1	62	Handle	1
26	Washer	2	63	Screw	1
27	Washer	2	64	Carpurator	1
28	Bolt	2	65	Gasket	1
29	Grommet	1	66	Screw	2
31	Retainer	1	67	Pipe	1
32	Stop wire	1	68	Gasket	1
33	Key	1	69	Guide air plate	1
34	Crankshaft	1	70	Screw	2
36	Bearing	1	71	Gasket	1
37	Ring	2	72	Screw	4

