



ASSEMBLY DIAGRAM AND PARTS LIST

A




NO.	Description	Qty.	NO.	Description	Qty.
A01	Nuts M5	2	A22	Piston clip	2
A02	Muffler cover	1	A23	Piston bearing $\Phi 11 \times \Phi 15 \times \Phi 12.5$	1
A03	Muffler	1	A24	Washer	2
A04	Muffler gasket	1	A25	Crankshaft	1
A05	Muffler bolt M5 x 84	2	A26	Woodruff key 3 x $\Phi 10$	1
A06	Screw M5x10	2	A27	Vacuum pipe $\Phi 3 \times \Phi 6 \times 70$	1
A07	Screw M5x20	4	A28	Vacuum pipe clip	2
A08	Cylinder	1	A29	Elbow	1
A09	Inlet pipe gasket	1	A30	High-temperature sleeve	1
A10	Inlet pipe	1	A31	Guide(LH)	1
A11	Screw M5x12	2	A32	Oil seal (left)	1
A12	Carburetor bracket	1	A33	Screw M5x30	5
A13	Screw M5x14	2	A34	Crankcase (left)	1
A14	Asbestos mat	1	A36	Snap ring	1
A15	Spacer	1	A37	Bearing 6202	2
A16	Lining ring	1	A38	Location pin $\Phi 6 \times 10$	3
A17	Bracket gasket	1	A39	Crankcase gasket	1
A18	Cylinder gasket	1	A40	Crankcase (right)	1
A19	Piston ring	2	A42	Oil seal (right)	1
A20	Piston	1	A43	Double-screw bolt M8x42	1
A21	Piston pin	1			

ASSEMBLY DIAGRAM AND PARTS LIST




NO.	Description	Qty.
B01	Screw M5x20	2
B02	Ignition coil	1
B03	Ignition cover	1
B04	Cord	1
B05	Oil seal plate	1
B06	Screw M4x8	2
B07	Flywheel	1
B08	Nut M8x1	1
B09	Start assy	1
B10	Start knob	1
B11	Start roop $\Phi 3 \times 950$	1
B12	Guide(LH)	1
B13	Rope mouth	1
B14	Screw M5x14	4
B15	Start cover	1
B16	Start spring	1
B17	Start teel-big	1
B18	Recoil spring	1
B19	Start teel-small	1
B20	Washer $\Phi 5.2 \times \Phi 16 \times 1$	1
B21	Screw ST4.8x14F	1
B22	Fan cover	1
B23	Switch damper	1
B24	On-off switch	1
B25	Ground stap	1
B26	Screw M5x10	1
B27	Spark plug L7T	1



NO.	Description	Qty.
C01	Front handle comp	1
C02	Screw ST4.8x16F	4
C03	Tower spring	1
C04	Tower spring body	1
C05	Chain catcher	1
C06	Screw M5x14	3
C07	Damper cover	5
C08	Screw ST4.8x14F	4
C09	Crankcase damper	3
C10	Fuel tank damper	2
C11	Stopper	1
C12	Balancer seat	1
C13	Balancer assy	1
C14	Trigger spring	1
C15	Knob cap	1
C16	Spring	1
C17	Throttle interlock pin	1
C18	Throttle interlock arm	1
C19	Rear handle cover	1
C20	Trigger	1
C21	Trigger pin $\Phi 6 \times 25$	1
C22	Screw ST4.8x20F	1
C23	Fuel tank	1


ASSEMBLY DIAGRAM AND PARTS LIST

D



NO.	Description	Qty.
D02	Top cover	1
D03	Screw M5x14	5
D04	Air filter cover knob	1
D05	Air filter cover knob washer	1
D06	Air filter cover	1
D07	Air filter damper	1
D08	Air filter	1
D09	washer	1
D10	Guide(T)	1
D11	Carburetor	1
D12	StudM5x39A	1
D13	Mainfold	1
D14	ScrewM5x50	2
D15	Manifold damper	1
D16	Choke rod damper	1
D17	Choke rod	1
D18	Damper	1
D19	Dust shield	1
D20	Throttle rod	1
D21	Fuel pipe	1
D22	Pendent	1
D23	Fuel filter assy	1
D24	Fuel cap	1
D25	Fuel cap washer	1
D26	Element	1


E



NO.	Description	Qty.
E01	Oil cap	1
E02	Oil cap washer	1
E03	Element	1
E04	Oil tank valve	1
E05	Oil tank value retainer	1
E06	Sponge	1
E07	Oil pipe	1
E08	Oil pump	1
E09	Oil pump pipe	1
E10	ScrewM4x14	2
E11	Oil pump cover	1
E12	ScrewM4x10	1
E13	Worm gear	3
E14	Sealed sponge	1
E15	Oil filter	1
E16	Clutch bearing $\Phi 12 \times \Phi 15 \times 14.5$	1
E17	Sprocket	1
E18	Clutch drum	1
E19	Clutch washer	1
E20	Clutch wedge	3
E21	Clutch bracket	1
E22	Clutch spring	1
E23	Clutch assy	1


ASSEMBLY DIAGRAM AND PARTS LIST

F



NO.	Description	Qty.
F01	Screw M5x10	2
F02	Spike bumper	1
F03	Screw M4x8	1
F04	Guide plate	1
F05	Guide plate gasket	1
F06	Chain guide	2
F07	Brake assy	1
F08	Brake damper	1
F09	Snap ring Φ 5	1
F10	Washer Φ 6.2xΦ 18x1	1
F11	Brake spring	1
F12	Front hand guard	1
F13	Stopper pin	1
F14	Snap ring Φ 3	1
F15	Front hand jacket	1
F16	Guard pin	1
F17	Stopper plate	1
F18	Snap ring Φ 4	1
F19	Nut M8x1.25	1
F20	Clutch cover	1
F21	Screw ST3.9x10F	3
F22	Brake spring cover	1
F23	Brake level(Sub)	1
F24	Brake level(Main)	1
F25	Brake level pin	1
F26	Screw ST3.9x8F	2
F27	Tensioner plate	1
F28	Tensioned bolt set	1
F29	Brake band	1
F30	Brake arm	1
F31	Brake spring(Main)	1
F32	Brake spring(Sub)	1
F33	Sawdust protector	1

G



NO.	Description	Qty.
G01	Guide bar cover	1
G02	chain	1
G03	Guide bar	1
G04	Oil bottle	1
G05	Tools	1
G06	Tool skit	1
G07	File	1
G08	Screwdriver	1
G09	Wrench	1
G10	S4 Hexagon ring spanner	1
G11	S3 Hexagon ring spanner	1
G12	Manual	1