


PARTS LIST

Item #	Description	Qty	Item #	Description	Qty
1	Bolt	1	41	Bolt	4
2	Spindle Assembly	1	42	Bolt	4
3	Bearing	2	43	Engine Base	1
4	Drum Assembly	1	44	Small Pulley	1
5	Nut	6	45	Engine	1
6	Washer	6	46	V - Belt	2
7	Bolt	6	47	Inner cover	1
8	Ring Gear	1	48	Hinge Shaft	1
9	Yoke Weld	1	49	Outer Cover	1
10	Bearing Housing	1	50	Pin	1
11	Bolt	4	51	Hand wheel	1
12	Washer	4	52	Washer	1
13	Guard Brake Upper	1	53	Nylon Bushing	1
14	Spindle	1	54	Nylon Bushing	1
15	Bearing	1	55	Spindle Assembly	1
16	Gear Guard	1	56	Guard Brake Lower	1
17	Bearing	1	57	Bolt	1
18	Bearing Housing	1	58	Washer	1
19	Speed Converter	1	59	Brake Jaw	1
20	Position Ring	1	60	Brake Handle	1
21	Gear	1	61	Brake Body	2
22	Position Ring	1	62	Bolt	4
23	Circlip	1	63	Frame Assembly	1
24	Bearing	1	64	Towpole	1
25	Circlip	1	65	Bolt	1
26	Speed Converter Cover	1	66	Bolt	3
27	Bearing Cap	1	67	Leg	1
28	Bolt	6	68	Nut	1
29	Circlip	1	69	Nut	4
30	Bolt	1	70	Bolt	4
31	Big pulley	1	71	Wheel Shaft	1
32	Gear Cap	1	72	Pin	2
33	Bearing	1	73	Seal Ring	2
34	Shaft	1	74	Bearing	2
35	Gear	1	75	Bolt	8
36	Position ring	1	76	Bearing Hub	2
37	Bearing	1	77	Bearing	2
38	Circlip	1	78	Tyre Assembly	2
39	Bearing Cap	1	79	Dust Cap	2
40	Bolt	9	80	Nut	8
			81	Latch Rubber	3

ASSEMBLY DIAGRAM



NOTE: Some parts are listed and shown for illustration purposes only, and are not available individually as replacement parts.