




PART NO.	DESCRIPTION	QTY
1	Guard cover	1
2	Reduction box	1
3	Engine	1
4	Plate	4
5	Straight nozzle	4
6	Plane bearing	1
7	Bigger plate	1
8	Pulley	1
9	Clutch	1
10	Lifting plate	1
11	Belt cover	1
12	Support for belt cover	1
13	Knock pin	1
15	Circlip	1
16	Pin rod	1
17	Knock pin shaft	1
18	Adjusting cable	1
19	Handle pipe	1
20	Handle wheel A	1
21	Screw stem nut	1
22	Fixing seat for plane bearing	1
23	Plane bearing51104	1
24	Adjusting screw stem	1
25	Handle wheel B	1
26	Handle	1
27	Blade350x150x1.7mm	4
28	Blade fixer	4
29	Adjusting device	
30	Cross screw	4
31	Cross	1
32	Fixing screw	8
33	Bending nozzle	4
34	V-belt	1
35	Torsional spring	4
36	Throttle cable	1
37	Throttle lever	1
38	Grip	2
39	Switch, engine stop	1
	Cable roller (Nylon)	1
	Iron pan (Optional)	1