

Parts list

Part	Description	Qty	Part	Description	Qty
1	cable and plug	1	51	cross screw M4x8	1
2	floating switch	1	52	spring gasket	1
3	pump rear housing	1	53	washer	1
4	screw	4	54	motor defend ring	1
5	washer	4	55	motor rear cover	1
6	cable sheath	1	56	wave washer	1
7	cable fixer	2	57	bearing	2
8	capacitor	1	58	rotor	1
9	cable block	1	59	startor	1
10	screw	3	60	motor front support	1
11	pump main housing	1	61	o ring	1
12	o ring	1		motor front cover	1
13	steel ball	1		o ring	1
14	pump base	1	62	frame seal	2
15	screw	3	63	machine seal	1
16	adaptor	1	64	defend ring	1
17	o ring	2	65	adjusting washer	1
18	output	1	66	impller	1
			67	nuts	1

Assembly diagram

